

ASSEMBLY AND INSTALLATION INSTRUCTIONS

OW21881BBZ / OW21881TB

WARNING: Turn off the main power at circuit breaker before installing fixture. AVERTISSEMENT: Coupez la source d'alimentation principale au panneau central de disjoncteurs avant d'installer le luminaire.

- NOTE: 1. Before installing, consult local electrical codes for wiring and grounding requirements.
 - 2. Read and save these instructions.





Installation Steps

Turn off the power at fuse or circuit box

- 1. Unscrew the end cap (D) and remove the rubber pad (E) from mounting strap unit (A).
- 2. Attach the mounting strap unit (A) to the outlet box by using two mounting screws (B). Adjust the length of the preinstalled threaded pipe if necessary.




- 3. Pull out the source wires from the outlet box. Make wire connections using wire connectors (C) as follows:
 - Connect the hot wire (usually black insulation) from the fixture to the black wire from the power source.
 - Connect the neutral wire (usually white insulation) from the fixture to the white wire from the power source.
 - Attach the fixture grounding wire (usually green with the insulation or bare wire) to the mounting strap unit (A) with the green grounding screw. Then, depending on local code, connect it to the house grounding wire with the wire connector (C).


Carefully put all of the wires back into the outlet box.

- 4. Attach the backplate of the fixture to the mounting strap unit (A) by inserting the threaded pipe, then secure it with the rubber pad (E) and the end cap (D).
 - Note: With silicone caulking compound, caulk completely around where the backplate meets with the wall surface to prevent water from seeping into the outlet box.
- 5. Unscrew the set screws to separate the frame from the fixture.
- 6. Install the bulb (not included). See relamping label at socket area or packaging for maximum wattage allowed.
- 7. Restore the frame back to the fixture by using the set screws.

Turn on the power at fuse or circuit box.

The following parts are available for reorder if damaged or missing.





1 Year Warranty

Vaxcel warrants all of our products against defects in workmanship and finishes for one year following the date of shipment.

Exclusions: This warranty does not include the failure of products from extreme acts of nature; environmental conditions not suited for the products intended use; operation in temperatures outside of the range specified in the instruction manual; usage with improper power supply, power surges or dips. For coastal locations, some corrosion is considered normal for the environment.

Vaxcel reserves the right to repair, replace or issue a credit for any properly installed product, provided it is returned per RMA instruction. This warranty is limited to the cost of the product only and does not extend to transportation, installation or replacement costs.

How can warranty service be obtained? info@vaxcel.com 1-800-482-9235

