



Assembling the fixture

1. Slide Rubber Gasket (F) down the wire to sit on the Bubble Glass Rod Assembly (H).
2. Slide Glass (D) down the wire until it sits on the Rubber Gasket of the Bubble Glass Rod Assembly (H).
3. Set Metal Cap (C) on the Glass (D), Secure with Metal knob (B). Do not move the Strain Relief (G) location as it is preset in the factory for safety purpose.
4. Please refer to the Jack Installation Instruction for instruction on installing the Jack.
5. The lamp is match with Rapid Jack canopy of the item#EC85000-EC85025

