Assembly Instruction For EC95003/EC95004/EC95013/EC95014/EC95018/EC95022/EC95025

Turn off power at breaker for outlet fixture is being installed to.

- 1. Position the Backplate (B) on the ceiling at desired location and mark the place for the anchor at the extra 4 holes location of the Backplate (B).
- 2. Drill pilot holes on the marked spots and insert Plastic Anchors (A).
- 3. Attach the Backplate (B) to the outlet box using the Screws (C) provided. Use the Wood Screws (G) to further secure the Backplate (B) to ceiling at the 4 plastic anchor (A) place.
- 4. Wire Jack Canopy per Diagram A
- 5. Attach Jack Canopy (D) to the Backplate (B) with Screws (E) and tighten Screw (E) to secure. Please refer to Diagram B for details.
- 6. Attach Cap (F) to the Socket (H), then insert the Jack to the Socket (H). (Jack is not provided).
- 7. Install Jack Fixture follow instruction provided with Jack Fixture.

