

TFA9900

INSTALLATION INSTRUCTIONS

Please read carefully and save these instructions, as you may need them at a later date.

CAUTION

WARNING: Risk of Fire. Consult a qualified electrician to ensure correct branch circuit conductor. Min 90°C supply conductors.

Turn off the main power at the circuit breaker before installing the fixture, in order to prevent possible shock.

GENERAL

All electrical connections must be in accordance with local and National Electrical Code (N.E.C.) standards. If you are unfamiliar with proper electrical wiring connections obtain the services of a qualified electrician.

Remove the fixture and the mounting package from the box and make sure that no parts are missing by referencing the illustrations on the installation instructions.

ASSEMBLY AND INSTALLATION

1. Insert the square tube(9) into the base(11). Tighten the screw and nut(12) with wrench (13).
2. Insert the round tube(7) into the square tube(9), using the stick(8) to secure it.
3. Slide the shade(3) up along the stem(4), and secure the shade with the metal disk(6)
4. Insert the bulb into the socket(5)
5. Put the acrylic diffuser under the shade(3), and lock it with finial(1)

DO NOT USE BARE HANDS TO TOUCH BULB.

INSTALLATION IS NOW COMPLETE

