

## TFA9307 INSTALLATION INSTRUCTIONS

Please read carefully and save these instructions, as you may need them at a later date.

## **CAUTION**

WARNING: Risk of Fire. Consult a qualified electrician to ensure correct branch circuit conductor. Min 90°C supply conductors.

Turn off the main power at the circuit breaker before installing the fixture, in order to prevent possible shock.

## **GENERAL**

All electrical connections must be in accordance with local and National Electrical Code (N.E.C.) standards. If you are unfamiliar with proper electrical wiring connections obtain the services of a qualified electrician.

Remove the fixture and the mounting package from the box and make sure that no parts are missing by referencing the illustrations on the installation instructions.

## ASSEMBLY AND INSTALLATION

- 1. Carefully unpack all parts from cartons.
- 2. Place the lamp base(D) on a flat surface.
- 3. Thread the Screw(B) through the Washer(C) and the lamp base(D) into the Tube(E) and secure with the tool(A) until tight.
- 4. Place the Tube(I) into the Tube(E) and fasten the Screw (F) until tight.
- 5. Place the Shade(K) over the Socket(J) and secure with Ring(L) until tight.
- 6. Install light bulb(not included) into the socket(J)

DO NOT USE BARE HANDS TO TOUCH THE BULB.

INSTALLATION IS NOW COMPLETE

