



ASSEMBLY/INSTALLATION INSTRUCTIONS

Note: If you find any Tabs do not engage Glass Panels well during assembly, please push the Tabs until they are attaching onto the Glass Panels.

1. Before beginning the assembly/installation, carefully unpack and identify parts, referring to the illustration.
2. Turn the electrical power to the installation point OFF at circuit breaker.
3. Open the DOOR and install the correct bulbs referring to the fixture markings and/or labels for maximum wattage. Proceed to close the DOOR by placing the BOLT onto the BOLT HOLDER.
4. Carefully fit the POST FITTER over the end of the POST (not supplied), making sure the POST FITTER is fully seated. Mark the drill point for the (3) MOUNTING SCREWS, using (3) MOUNTING HOLES as reference. After marking hole locations, remove FIXTURE from POST and drill 1/8" pilot holes for screws.
5. **Makin the wiring connections:**
 Using wire connectors(not supplied), connect the WHITE SUPPLY WIRE from the POST to the WHITE FIXTURE WIRE; connect the BLACK (or RED) SUPPLY WIRE from the POST to the BLACK FIXTURE WIRE. Connect the SUPPLY GROUND WIRE to the FIXTURE GROUND WIRE. Wrap each connection with approved electrical tape.
6. Coat the top 1" of the POST with CLEAR SILICONE CAULK (not supplied) and position the POST FITTER onto the POST. Be sure to seat it completely, aligning the holes in the FITTER with the 1/16" PILOT HOLES drilled into the POST. Secure the FIXTURE to POST with (3) MOUNTING SCREWS (supplied).
7. Thread the BARS into the CONNECTORS on the side of the POST FITTER and hand tighten until snug.
8. Restore power to installation point ON. Retain this sheet for future reference.

**IF IN DOUBT ABOUT ELECTRICAL INSTALLATION,
 CONSULT A LICENSED ELECTRICIAN!**