

# ASSEMBLY INSTRUCTIONS

ITEM NO: BO-2753TR

1. CAREFULLY UNPACK AND PLACE ALL PARTS ON A SMOOTH SURFACE AND LAY THEM UP AS PER THE SKETCH.
2. SCREW TUBE A INTO BASE,SCREW CONNECTOR A INTO TUBE A
3. SCREW TUBE B INTO CONNECTOR A,SCREW CONNECTOR B INTO TUBE B
4. SCREW TUBE C INTO CONNECTOR B,PULL THE EXTRA CORD FROM BOTTOM OF BASE, SCREW SOCKET ASSEMBLY INTO TUBE C.
5. PUT SHADE ONTO SOCKET ASSEMBLY AND TIGHTEN WITH SOCKET RING
4. SCREW BULB INTO THE SOCKET,INSERT THE POWER PLUG INTO PLUG SEAT TO USE

**Recommended (1) 3-WAY 150 WATT Type “A” Bulb**

**Or (1) maximum 13WATT CFL Bulbs (Bulbs not included)**

**SAVE THESE INSTRUCTIONS FOR FUTURE REFERENCE.**

