ASSEMBLY INSTRUCTIONS

ITEM DESCRIPTION:

ITEM NO.: <u>DMS16_NAME</u>: <u>CORINNA PENDANT</u> MATERIAL TYPE: Rattan<u>, Abaca Rope, Metal</u> FINISH: <u>Brass_Plating, Natural</u> SOCKET TYPE: <u>E26_</u>SOCKET QTY: <u>1</u> BULB WATTAGE: <u>60W_</u>VOLATGE: <u>110-120V</u> ITEM NET WEIGHT: <u>20.94 LB</u>

| Constant and the second | Ċ | | | ð. |
|-------------------------|---------|---|-----|-------|
| Е | F | G | | Н |
| PARTS INCLUD | ED: | | | |
| MOUNTING PLATE | | | (E) | QTY 1 |
| CANOPY | | | (F) | QTY 1 |
| SOCKET | | | (G) | QTY 1 |
| SHADE | | | (H) | QTY 1 |
| | | - | | |
| | Dennes | | | |
| А | В | С | | D |
| HARDWARE IN | CLUDED: | | | |
| Mounting Screws | | | (A) | QTY 2 |
| Canopy Screws | | | (B) | QTY 2 |
| Plastic Wire Connector | | | (C) | QTY 3 |
| Green Ground Screw | | | (D) | QTY 1 |

TO INSTALL YOU WILL NEED:

• 2 people recommended. • Phillips Screwdriver

These instructions are provided for safety.

It is very important that they are read carefully and completely before beginning installation.

We strongly suggest that all hard-wired fixtures must be installed by a professional electrician.

For customer service questions call 1-800-338-2150

TO ASSEMBLE:

- 1. Shut off the main electrical supply from the main fuse box/ circuit breaker.
- 2. Carefully unpack all fixture parts and hardware and lay them on a soft surface for assembly.
- 3. Gently pull wiring down from ceiling junction box and allow to hang.
- 4. Remove mounting plate from the canopy by unscrewing the collar.
- 5. Carefully inspect the pendant's fixture wires.

Neutral fixture wire: White Hot fixture wire: Black Ground wire: Green

- 6. Wrap ground wire of lamp assembly and ground wire of junction box together and fasten together with a wire nut and wrap the connection with electrical tape.
- 7. Attach the neutral fixture wire from the pendant to the neutral junction box wire (usually white). Fasten each together with a wire nut and wrap the connection with electrical tape.
- 8. Attach the hot fixture wire from the pendant to the hot junction box wire (usually black). Fasten each together with a wire nut and wrap the connection with electrical tape.

DO NOT REVERSE THE HOT AND NEUTRAL CONNECTIONS OR SAFETY WILL BE COMPROMISED.

- . Gently tuck the wire connections neatly into the ceiling junction box.
- 10. Place the mounting plate over the center of the ceiling junction box.
- 11. Align holes in mounting plate with holes in junction box and attach with two mounting bolts. Secure bolts with a Phillips head screwdriver.
- 12. Push canopy up over the mounting plate until it is flush with the ceiling.
- Push collar through hole in canopy and thread onto nipple on the mounting plate. Secure by turning collar clockwise until canopy is flush with the ceiling.
- 14. Restore power to junction box and test fixture. Insert XYZ bulb into fixture. DO NOT EXCEED SPECIFIED WATTAGE OF PENDANT.

CARE INSTRUCTIONS:

Wipe with a soft, dry cloth. To protect finish, avoid the use of chemicals and household cleaners.

