

ASSEMBLY INSTRUCTIONS

ITEM DESCRIPTION:


ITEM NO.: DRC10 NAME: SINCLAIR OVAL CHANDELIER

MATERIAL TYPE: METALL+ GLASS FINISH: ANTIQUE BRASS+ SMOKE LUSTER GLASS

SOCKET TYPE: E26 SOCKET QTY: 8

BULB WATTAGE: TYPE G50 60W

VOLTAGE: 100V-120V ITEM NET WEIGHT: 22.4KG



PARTS INCLUDED:

Mounting Plate (A)	Qty:1PC	Anchor (Q)	Qty:5PCS
Canopy(B)	Qty:1PC	Bracket(R)	Qty:1PC
Collar (O)	Qty:2PCS	Screw(S)	Qty:2PCS
Lamp Body(D)	Qty:1PC	Coupling (Z)	Qty:1PC
Hex Screw(E)	Qty:25PCS	Aircraft Wire (W)	Qty:1PC
Glass panel(F1)	Qty:32PCS	Allen Wrench(U)	Qty:1PC
Glass panel(F2)	Qty:12PCS	Strengthened Screw(T)	Qty:5PCS
Rod(G1,G2,G3,G4)	Qty:8PCS	Mounting Screw (J)	Qty:2PCS
Socket(H)	Qty:8PCS	Wire connection(K)	Qty:1PC
Thumb-Screw (I)	Qty:64PCS	Power Wire(L)	Qty:1PC

HARDWARE INCLUDED:

Mounting Screws	2	Hexangular Screw	24
Plastic Wire Connect	3	Allen Wrench	1
Green Ground Screw	1		

TO INSTALL YOU WILL NEED:

- 2 people recommended
- Phillips Screwdriver
- Allen Wrench

These instructions are provided for safety. It is very important that they are read carefully and completely before beginning installation of this chandelier.

We strongly suggest that all hard-wired fixtures must be installed by a professional electrician.



TO ASSEMBLE:

1. Shut off the main electrical supply from the main fuse box/ circuit breaker.
 2. Carefully unpack all fixture parts and hardware and lay them on a soft surface for assembly.
 3. Gently pull wiring down from ceiling junction box and allow to hang.
 4. Remove mounting plate(A) from the canopy(B) by unscrewing the mounting Screw(J).
 5. Position fixture in desired location on ceiling. The mounting plate features (2) holes for screw mounting. Mark these spots on the ceiling with a pencil to drill holes. Drill 2 holes on these spots and insert anchors(Q) into drilled holes.
 6. Pass the power wire(L) through the rod (G4),(G3),(G2)&(G1), screw the rod(G4) to lamp body(D) till tight,repeat the same operation on the rod(G3),rod(G2) and rod(G1).When you connect the rods,loosen the small hex screws(E) in the side hole first then tighten with allen wrench(U) after all rods are connected.Be sure all the hexangular screws are tight enough.
 7. Drill one hole on the ceiling and insert anchor(Q) into drilled hole, then fix bracket(R) to the ceiling with strengthened screw (T) by screwing into anchor(Q). Remove the coupling(Z) from the aircraft wire(W) by loosening (2) screws(S). Pass the aircraft wire(W) through (2) holes on the bracket(r), then pass the aircraft wire(W) through (2) holes on the coupling(Z) and fix with (2) screws(S) as Fig1. or you can find more details on next page. Be sure to tighten two screws attached on the coupling(Z).
 8. Carefully inspect the chandelier's fixture wires.
Neutral fixture wire: It has very fine ridged molded into its plastic covering.
Hot fixture wire: It has a smooth covering
Ground wire: Bare wire
 9. Wrap ground wire of lamp assembly and ground wire of junction box together and fasten together with a wire nut and wrap the connection with electrical tape.
 10. Attach the neutral fixture wire from the chandelier to the neutral junction box wire. Fasten each together with a wire nut and wrap the connection with electrical tape.
 11. Attach the hot fixture wire from the chandelier to the hot junction box wire. Fasten each together with a wire nut and wrap the connection with electrical tape.
- DO NOT REVERSE THE HOT AND NEUTRAL CONNECTIONS OR SAFETY WILL BE COMPROMISED.
12. Gently tuck the wire connections(K) neatly into the ceiling junction box.
 13. Place the mounting plate(A) over the center of the ceiling junction box.
 14. Align holes in mounting plate(A) with holes in junction box and attach with two mounting bolts(J). Secure bolts with a Phillips head screwdriver. Then secure the mounting plate by inserting the strengthened screw(T) into the anchor(Q) and tightening clockwise with a screwdriver.
 15. Push canopy(B) up over the mounting plate(A) until it is flush with the ceiling. Push collar(O) through hole in canopy(B) and thread onto nipple on the mounting plate(A). Secure by turning collar(C) clockwise until canopy(B) is flush with the ceiling.
 16. Insert 8 TYPE G50 60W bulbs (or /CFL 12W OR /LED 10W, not included) into socket(H). DO NOT EXCEED THE SPECIFIED WATTAGE.
 17. Attach the glass panel (F1, F2) to the lamp body (D), and then secure it with a set of thumb screws (I). Repeat the same operation on the other glass panels (F1, F2).
 18. Restore power to the junction box and test fixture.

CARE INSTRUCTIONS:

Wipe with a soft, dry cloth. To protect finish, avoid the use of chemicals and household cleaners.

For customer service questions call 1-800-338-2150

ARTERIOS

AIRCRAFT WIRE ASSEMBLY INSTRUCTIONS

1. Attach The Aircraft Wire(W) To A Solid Structure In Accordance To Local Building Code.
2. Position The Bracket(R) In Desired Location On Ceiling And Mark One Spot With Pencil To Drill Hole.
Drill 1 Hole On The Spot And Insert Anchor(Q) Into Drilled Hole.
3. Fix Bracket(R) With Strengthened Screw (T) By Screwing Into Anchor(Q).
If Attach To Cement Ceiling, Use Anchor(Q) First Then Screw Strengthened Screw (T) Into The Anchor(Q).
If Attach To Wood Ceiling, Thread Strengthened Screw (T) Directly Into Ceiling.
4. Remove The Coupling(Z) From The Aircraft Wire(W) By Loosening The (2) Screws(S) Before Installation.
5. Pass The Aircraft Wire(W) Through The (2) Holes On The Bracket(R) As The Drawing.
6. Then Pass The Aircraft Wire(W) Through The (2) Holes On The Coupling(Z) And Fix With (2) Screws(S) As The Drawing And Then Tighten (2) Screws(S). With A Screwdriver.

