

ASSEMBLY INSTRUCTIONS

ITEM NO: BO-2799TB

1. CAREFULLY UNPACK AND PLACE ALL PARTS ON A SMOOTH SURFACE AND LAY THEM UP AS PER THE SKETCH.
2. SQUEEZE THE SPRING TABLS (F) ON THE SOCKET (G) AND PLACE THE SOCKET THROUGH THE CENTER HOLE (H) ON THE BOTTOM OF THE SHADE (E) . THE SPRING CLIPS WILL ENGAGE THE SOCKET IN PLACE AFTER ASSEMBLY .
3. SCREW THE THREADED ROD(D) INTO LAMP BODY SECTION(E). PUT WASHIER(C) ONTO THE THREADED ROD(D). PLACE SHADE (B) ONTO THE THREADED ROD (D) WITH THE FINIAL (A) CLOCKWISE TO TIGHTEN.
4. INSERT THE POWER PLUG INTO AN OUTLET AND ENJOY!

Use MAX 2*60 Wattage type A bulb (bulb not included)
1x 7W Type C (bulb included)

IMPORTANT SAFETY INSTRUCTIONS:

SAVE THESE INSTRUCTIONS FOR FUTURE REFERENCE.

THIS PORTABLE LAMP HAS A POLARIZED PLUG (ONE BLADE IS WIDER THAN THE OTHER) AS A FEATURE TO REDUCE THE RISK OF ELECTRIC SHOCK. THIS PLUG WILL FIT IN A POLARIZED OUTLET ONLY ONE WAY. IF IT DOES NOT FIT FULLY IN THE OUTLET, REVERSE THE PLUG. IF IT STILL DOES NOT FIT, CONTACTA QUALIFIED ELECTRICIAN. NEVER USE WITH AN EXTENSION CORD UNLESS THE PLUG CAN BE FULLY INSERTED. DO NOT ALTER THE PLUG.

