

# ASSEMBLY AND INSTALLATION INSTRUCTIONS

**WARNING:** TO AVOID RISK OF ELECTRICAL SHOCK, BE SURE TO SHUT OFF POWER WHILE INSTALLING OR SERVICING THIS FIXTURE.

**NOTE:** Before installing, consult local electrical codes for wiring and grounding requirement.

## Installation Steps:

1. Shut off the power at the circuit breaker box. Remove old fixture and all hardware from Outlet Box.
2. Carefully unpack your new fixture and lay out all the parts on a clear area. Take care not to lose any small parts necessary for installation.
3. Thread the two mounting screws into the pre-drilled holes in the mounting plate spaced the same distance apart as the holes in the canopy. Attach the mounting plate to the outlet box with the two box screws as shown. The side of the mounting plate marked "GND" must face to out. **The outlet box is not included.**
4. Take this LED illuminant to the fixture plate, the magnet conglutinating with the fixture plate, then raise the power plug insert the socket.
5. Install the diffuser into the shade frame, fixed with the iron sheets.
6. Attach the assembled shade onto the fixture plate, aligning the top studs of shade with the fixture plate's slots, now, rotate the shade until the studs are seat in the slots, then lock it securely with the column nut.
7. While holding the canopy and assembled fixture, hanging at both open links of the chain to the small loop, close the open links.
8. Take this assembled fixture to ceiling outlet box, connect the electrical wires.
9. **NOTE: make wires connections:**
  - \*\*Attach fixture bare copper ground wire to supply ground wire using a wire nut or attach them to them mounting plate with a green ground screw.
  - \*\*Attach fixture ridge wire from lamp body to supply white wire or ridge wire from power source with a wire nut.
  - \*\*Attach fixture smooth wire from lamp body to supply black wire or smooth wire from power source with a wire nut.
  - \*\*Observing: positive wire with positive wire, negative wire with negative wire, ground wire with ground wire.
10. Make sure all wire connectors are secured and do not easily pull off with the slight tug. After wires are connected, tuck them carefully inside the outlet box.
11. Raise the canopy on to the outlet box, aligning screws on mounting plate with mounting holes in canopy and lock it securely with the finials.
12. Your installation is now complete. Return power to the outlet box and test the lamp body.

