

ASSEMBLY AND INSTALLATION INSTRUCTION

WARNING: SHUT POWER OFF AT FUSE OR CIRCUIT BREAKER!

NOTE: BEFORE INSTALLING, CONSULT LOCAL ELECTRICAL CODES FOR WIRING AND GROUNDING REQUIREMENT.

Installation Steps:

1. Shut off the power at the circuit breaker box. Remove old fixture and all hardware from Outlet Box. Carefully unpack your new fixture and lay out all the parts on a clear area. Take care not to lose any small parts necessary for installation.
2. Thread the two mounting screws into the pre-drilled holes in the mounting plate spaced the same distance apart as the holes in the canopy. Attach the mounting plate to the outlet box with the two outlet box screws as shown. The side of the mounting plate marked "GND" must face out.
3. **See Fig.1.** Place the arcuation frame at the center of the lamp body, aligning the top square salient point and bottom indentation, lock it securely with the mounting screws. Feed the wires from lamp holder through pipe and lamp body 's center thread pipe, thread the thread nipple to inside of pipe, connect all the parts together until secure.
4. **See Fig.2 and Fig.3.** Attach the silica gel strips into arcuation face, then place the glass shade onto the arcuation in the lamp body frame.
5. **See Fig.4.** Place the arm onto the lamp body frame, aligning the top and bottom square salient point, lock it securely with the mounting screws. **See Fig.5.** Feed the wires from lamp body through thread pipe/ canopy/ spring shim and fixture ground wire, lock them securely with the wing nut.
6. Guide the supply wires and ground wire from outlet box through the center hole on the mounting plate.
7. **Make wire connections:**
 - attach fixture ground wire to supply ground wire using a wire nut or attach them to the mounting plate with a green ground screw.
 - attach white wire from light to white wire from power source with a wire nut.
 - attach black wire from light to black wire from power source with a wire nut.**Observing: ground wire with ground wire, neutral wire with neutral wire, hot wire with hot wire.**
*****Make sure all wire connectors are secured and do not easily pull off with the slight tug.**
8. Once all wires are connected, tuck them carefully into outlet box. Raise the canopy on to the outlet box, aligning screws on mounting plate with mounting holes in canopy and lock it securely with the column nut.
9. Install bulbs (not included) (Please do not exceed the maximum capacity which is recommended on the fixture.)
10. Your installation is now complete. Return the power to the outlet box and test the fixture.

