M13203 INSTALLATION INSTRUCTIONS SHEET

START FROM HERE


- Make sure power is completely off at the fuse box.Have your fixture installed by a qualified licensed
- electrician
- Prepare everything in clear area.
- Wear gloves at all times during this installation.Read instructions carefully before you start assembly.
- Keep this instructions calendify before you start assert
 Keep this instruction sheet for future reference.
 Technical Support: 1-844-628-8368

Please Note:

• All Matteo Lighting fixtures come with pre-wired module(s).

• Unless instructed to do so, please do not touch any part of the module(s) as unnecessary contact with the module could cause permanent damage.

THIS LUMINAIRE MUST BE MOUNTED OR SUPPORTED IN A JUNCTION BOX CE LUMINAIRE DOIT ÊTRE MONTÉ OU SUPPORTÉ DANS UNE BOÎTE DE JONCTION



- Ensure main supply is switched off.
- Connect the mounting bracket onto juction box by screws (1).
- Connect wires (2) according to color (White to White, Black to Black). Connect all earth lug together onto the crossbar with green screw to tight.
- Fit canopy and body onto mounting bracket with screws (3).
- Install the lamps (4).
- Install the shade (5).
- Reconnect power.
- Lamping: E26 LED 10W Max(not included).

WARNING:

- This fitting must be earthed.
- Disconnect power and allow fitting to cool down before cleaning or changing the lamp.

