
ASSEMBLY INSTRUCTIONS









Claymore Tall Sconce

Item # CHD 1627

WE RECOMMEND INSTALLATION OF THIS LIGHTING FIXTURE BE DONE BY A LICENSED ELECTRICIAN.

WARNING***SWITCH OFF THE MAIN ELECTRICAL SUPPLY FROM THE MAIN FUSE BOX/CIRCUIT BREAKER BEFORE INSTALLATION.

INSPECT ITEM CAREFULLY BEFORE ATTEMPTING TO INSTALL. IF THERE IS ANY DAMAGE OR OBVIOUS DEFECT. DO NOT INSTALL.

ITEM MAY NOT BE RETURNED ONCE IT HAS BEEN INSTALLED.

NOTE: CAREFULLY UNPACK EACH PIECE IN TOP LAYER OF PACKING PRIOR TO REMOVING. RETAIN ALL PACKING MATERIAL UNTIL INSPECTION AND INSTALLATION ARE FINAL.

- 1. Carefully remove all parts from the box.
- 2. Remove the mounting plate (B) from the backplate (D) by loosening the finials (E).
- 3. Affix mounting plate (B) to the outlet box and secure with mounting screws (C).
- 4. Drill 2 holes on the wall and make sure the distance will match to the fixture exactly.
- 5. Attach anchors (H) to the wall holes.
- 6. Install the bracket (I) to the anchors (H) and secure with screws (J).
- 7. Connect the hot wire (BLACK) from the fixture to the hot wire from the outlet box (usually BLACK). Fasten them together with a plastic wire connector (A) provided and wrap the connection with electrical tape.
- 8. Repeat this procedure for the neutral wire (WHITE) from the fixture to the wire from the outlet box (usually WHITE).
 - DO NOT REVERSE THE HOT AND NEUTRAL CONNECTIONS OR SAFETY WILL BE COMPROMISED.
- Connect ground wire from the fixture (bare copper) to ground wire from the outlet box (usually green or copper in color).
- IT IS IMPERATIVE THAT THIS FIXTURE BE GROUNDED.
- 10. Attach the backplate (D) to the mounting plate (B) and secure with finials (E).
- 11. Insert bulb (not included) into the socket.
- 12. Hang the metal leaf (F) onto bracket (K) and (I).
- 13. Installation is complete, turn on power at fuse or circuit breaker.



^{***}Clean with a dry, soft cloth only. Use no harsh abrasives or chemical agents.