



## Assembly Instruction For **E21310**

It is recommended that this fixture be installed by a licensed electrician.

1. Turn off breaker at electrical panel
2. Assemble metal shade J to framework C using flathead screw A and ball-nut H.
3. Install mounting bar to outletbox.
4. Adjust cables to proper height.
5. Install fixture to outlet using nipple and cap nut provided.
6. Install crystal strands B to rows D, E, and F.
7. Install 40 watt Xenon bulbs into sockets.

**Warning!!!** Xenon lamps burn extremely hot. Turn fixture off and allow bulbs to cool at least 15 minutes before touching.

