

Assembly Instruction Sheet #IS-5430P16

For Style 5430P16

Tools Required: Flathead screwdriver, Phillips screwdriver, pliers, wire cutters, wire strippers, electrical tape, safety glasses.
Light Source: (5) G9 Base Bulb 40W Maximum (Not Include).




Estimated Assembly Time: 15-30 minutes

















Preparation: Identify and inspect all parts before beginning installation. Check package content list and diagrams below to be sure all parts are present. If any parts are missing or damaged, do not attempt to assemble, install, or operate the fixture. Contact customer service for replacement parts.

⚠ Warnings and Cautions

Turn off electricity at circuit breaker or main fuse box before installation. Consult a licensed electrician if in doubt. These instructions are provided for your safety. It is very important you read them completely before installing the fixture. We strongly recommend that a licensed, professional electrician perform the installation. Disconnect fixture from power source before replacing bulbs. Make sure bulbs are given sufficient time to cool before removal.



Package Contents

 Fixture Body x1
 Ceiling Canopy X1
 Middle Rod
 B1 4" 2pcs
 B2 6" 1pcs
 B3 12" 5pcs

 14mmx6
 14mmx8
 14mmx8
 14mmx10
 14mmx9
 14mmx9
 14mmx10
 14mmx10
 30mmx1
 30mmx1
 30mmx1
 30mmx1
 63mmx1
 63mmx1
 63mmx1
 63mmx1

Hardware Contents

PART	DESCRIPTION	QUANTITY
CC	Wire nut	2pcs
DD	Screw	2pcs

 BB
 CC

STEP 1- Release Mounting bracket from Ceiling Canopy .




Figure 1

STEP 2 - Install Rods to Fixture Body




Figure 2

STEP 3 - Attach Mounting bracket to Outlet Box

A. Pass the supply wires through the Mounting bracket (EE). Attach the Mounting bracket (EE) to the Outlet Box with the head of the Green Ground Screw facing you. Secure it with Outlet Box Screws. Tighten until snug.




Figure 3

STEP 5 - Install Ceiling Canopy to Ceiling




Figure 5

STEP 4 - Wire Connections

A. Use standard wire connectors to make all wire connections. Twist connectors until wires are tightly joined together. Wrap each connection with approved electrical tape and carefully stuff all the connected wires into the Outlet Box.




Figure 4

STEP 6-Install bulb and Crystal.




Figure 6