

ASSEMBLY INSTRUCTIONS:

ITEM NO : BO-2671FL

CAREFULLY UNPACK AND PLACE ALL PARTS ON A SMOOTH SURFACE AND LAY THEM UP AS PER THE SKETCH.

1. SCREW PLATE(B), CONE TUBE (C) INTO BASE (A), LOOSE NUT (D), PULL AND ADJUST POLE (E) TO DESIRED HEIGHT AND TIGHTEN NUT (D) AGAIN. PULL THE CORD FROM THE BASE IF IT IS DIFFICULT TO ADJUST POLE (E).
2. SCREW HARP (G) INTO SADDLE (F).
3. PUT SHADE (H) (NO INCLUDED IN THIS PACKAGE) ONTO HARP (G) AND TIGHTEN WITH FINIAL (I), ADJUST THE SHADE TO HORIZONTAL.
4. INSTALL A RECOMMEND BULB (NOT INCLUDED).
5. INSERT THE POLARIZED PLUG INTO AN OUTLET.

TURN ON THE SWITCH AND ENJOY YOUR LAMP!!!

**USE 3-WAY 150 WATTAGE (MAXIMUM)
TYPE A BULB (BULB NOT INCLUDED)**

IMPORTANT SAFETY INSTRUCTIONS:

THIS FLOOR LAMP HAS A POLARIZED PLUG (ONE BLADE IS WIDER THAN THE OTHER) AS A SAFETY FEATURE TO REDUCE THE RISK OF ELECTRIC SHOCK. THIS PLUG WILL FIT IN A POLARIZED OUTLET ONLY ONE WAY. IF IT DOES NOT FIT FULLY IN THE OUTLET, REVERSE THE PLUG. IF IT STILL DOES NOT FIT, CONTACT A QUALIFIED ELECTRICIAN. NEVER USE WITH AN EXTENSION CORD UNLESS THE PLUG CAN BE FULLY AND EASILY INSERTED. DO NOT ATTEMPT TO ALTER THE PLUG.

SAVE THESE INSTRUCTIONS FOR FUTURE REFERENCE.

