

ASSEMBLY INSTRUCTIONS FOR YOUR
WILLIAMSBURG TYRIE CHANDELIER

IMPORTANT SAFETY INSTRUCTIONS:

- * These instructions are provided for your safety. It is very important that they are read completely before beginning the installation of your fixture.
- * **WE STRONGLY RECOMMEND INSTALLATION BY A LICENSED ELECTRICIAN.**
- * Turn off power at switch before replacing bulbs, making sure fixture has had sufficient time to cool down.
- * If any special control devices are used with this fixture, follow the instructions carefully to assure full compliance with N.E.C. requirements. If there are any questions, contact a qualified electrical contractor.

ASSEMBLY INSTRUCTIONS:

1. SHUT OFF THE MAIN ELECTRICAL SUPPLY AT FUSE BOX/ CIRCUIT BREAKER.
2. Remove all parts from carton. Do not throw away any parts.
3. Pull cord taut from above and thread bottom extension (J) onto nipple exiting housing (K).
4. Remove quick link (G) from hang straight (F). Keep quick link (G) attached to chain (H).
5. Remove cross bar (A) (with threaded nipple (C) and hang straight (F) attached) from canopy (D). Do this by unthreading collar (E) from hang straight (F). Canopy (D) will slip over hang straight (F). Set the canopy (D) and collar (E) aside.
6. Affix cross bar (A) (with threaded nipple (C) and hang straight (F) attached) to ceiling outlet box using screws (B) provided.
7. Measure desired drop for fixture to hang and add/remove chain links (H) with chain break tool (not included).
8. Attach quick link (I) to extension loop (J).
9. Slip collar (E) over chain (H) so it rests on loop (J). Slip canopy (D) over chain (H) so it also rests on loop (J).
10. Lift fixture to ceiling and secure quick link (G) to hang straight (F). Guide the wire exiting the fixture through the center of collar (E) and canopy (D). Continue to guide the wire through chain (H), quick link (G) and through the center of hang straight (F) and threaded nipple (C).
11. Make proper electrical connections described in steps 12 - 14. A LICENSED ELECTRICIAN IS RECOMMENDED.
12. Attach ground wire from fixture (green or silver in color) to ground wire from outlet box. Fasten wires together with wire nut (P) and tightly wrap connection with electrical tape.
13. Attach hot wire from fixture (black in color or smooth side of wire) to hot wire from outlet box. Fasten wires together with wire nut (P) and tightly wrap connection with electrical tape.
14. Attach neutral wire from fixture (white in color or ribbed side of wire) to neutral wire from outlet box. Fasten wires together with wire nut (P) and tightly wrap connection with electrical tape.
15. Carefully push wire connections back into ceiling outlet box.
16. Slide canopy (D) up chain (H) and hold flush against ceiling. To secure position of canopy (D), slide collar (E) up the chain and thread it onto hang straight (F). Turn until hand tight.
17. Remove flange (M) and spacer (N) from socket (O). Carefully slide glass shade (L) onto socket (O).
18. Slide spacer (N) over socket (O). Thread flange (M) onto socket (O) until hand tight to secure spacer and shade. Repeat steps 17-19 for remaining shades.
19. Install six 100W MAX. Type A, medium base bulbs into the sockets.
20. Reconnect main electrical supply from the fuse box/ circuit breaker and test the fixture.

To clean, use soft cloth only. Do not use any chemical or abrasive cleaners.

ASSEMBLY INSTRUCTIONS FOR YOUR WILLIAMSBURG TYRIE CHANDELIER

