WARNING:

This fixture is intended for installation in accordance with the National Electrical Code (NEC) and all local code specifications. If you are not familiar with code requirements, installation by a certified electrician is recommended.

ANY QUESTIONS CALL: 800-613-3261 M-F 8:00AM-6:00PM ET

CAUTION: To prevent shock, only plug in lamp after lamp assembly is complete.

WARNING: This portable lamp has a polarized plug (one blade is wider than the other). As a safety feature, this plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Never use with an extension cord unless plug can be fully inserted. Do not attempt to work around this safety feature.

Before assembly, remove all parts and part packages from box. If anything is missing, please contact the retailer from which the product was purchased.

- 1. Carefully pull lamp cord from lamp base (A). Pull lamp cord taut. Screw bottom column (B) onto lamp base (A).
- 2. Screw center column (C) onto top of bottom column (B).
- 3. Screw top column (D) onto top of center column (C).
- 4. Pass hole in bracket on inside of shade (E) over socket. Thread socket ring (F) onto socket. Tighten socket ring (F) to secure shade (E) in place.
- 5. Insert recommended bulb (not included) into socket. **WARNING:** Verify correct bulb wattage marked on socket of lamp. DO NOT exceed maximum bulb wattage.

