

## ⚠ WARNINGS AND CAUTIONS

**Important: ALWAYS** be sure to disconnect power before re-lamping or wiring the fixture. Read these instructions completely before starting installation.

To avoid the risk of fire and/or shock fixture must be installed in compliance to national and local electrical and building codes.

If an existing fixture is being replaced take special notice of which wires were connected in the outlet box.

**DO NOT SEPARATE ANY WIRES THAT MAY BE EXISTING IN THE JUNCTION BOX**  
**DO NOT DAMAGE THE INSULATION OF JUNCTION BOX WIRES.**

In Regular circumstances the BLACK wire will be "live", WHITE will be "neutral" and GREEN or BARE COPPER will be "ground". In older buildings it is always good practice to reconfirm the polarity of the wiring.

### NOTICE

- The important safeguards and instructions outlined in this sheet cannot cover all possible conditions and situations that may occur. It must be understood that caution and certain care factors must be followed. These instructions are provided for your safety and we highly recommend that a licensed, trained electrician install this unit.

### ASSEMBLY INSTRUCTIONS

#### Step 1

Remove fixture from its original package.

#### Step 2

Separate mounting plate (1c) from canopy (2a) by loosening the two canopy pivots (2b).

#### Step 3

Secure mounting plate (1c) to mounting surface with anchors (1f) and screws (1g)

**Important: This fixture must be mounted independently from junction box, additional means of support is required.**

#### Step 4

Determine hanging height of fixture by securing rods (2d) to canopy pivot (2b) (See Illustration 1) and fixture (3a) after feeding fixture wires through rods.

#### Step 5

Attach support cables (1d) onto mounting plate (1c).

#### Step 6

Safety cable (5a) must be mounted independently from junction box, additional means of support is required.

#### Step 7

Make proper electrical connections (black to hot "L", white to neutral "N", ground to "GND") with wire nuts (1b) provided in hardware package.

#### Step 8

Secure canopy (2a) to mounting plate (1c) by attaching canopy pivot (2b) to RTN (1h) and secure with mounting collar nut (2c).

#### Step 9

Attach fixture shade (3c) to fixture socket (3h) with socket ring (3d) and secure with socket wrench tool (3b) (See Illustration 2). Install recommended lamps (4a) (not provided) (referred on the socket label for maximum wattage and type) to fixture sockets (3h).

You are now ready to enjoy your fixture.

