

LAMP ASSEMBLY INSTRUCTIONS

ITEM NO: 741TL

1. Unpack the lamp from carton carefully.
2. Pull handle (A) to adjust the lamp arm as shown in the figure.
3. Pull handle (B) to adjust the lampshade as shown in the figure.
4. Pull handle (C) to adjust the lamp arm as shown in the figure..
5. Install light bulbs (not included) after completing the previous step.
6. Turn on and adjust brightness with Dimmer Switch(D),

WARNING:

1. Use 1*MAX.100W type A bulb (not included) for the Table lamp .

2. Do not use polishes or cleaners on your lamp.

JUST WIPE CLEAN WITH SOFT CLOTH.

IMPORTANT SAFETY INSTRUCTIONS

This portable lamp has a polarized plug (one blade is wider than the other) as a safety feature to reduce the risk of electric shock. This plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Never use with an extension cord unless plug can be fully inserted. Do not attempt to defeat this safety feature.

