

1500 Cherokee Parkway, Suite 100, Acworth, GA 30102

P: 866-845-5451 • F: 866-816-6165

E: service@acclaim-lighting.com • www.acclaim-lighting.com

# Item No . BF7134 INSTALLATION INSTRUCTIONS

Please read carefully and save these instructions, as you may need them at a later date.

#### **CAUTION**

WARNING: Risk of Fire. Consult a qualified electrician to ensure correct branch circuit conductor. Min 90°C supply conductors.

Turn off the main power at the circuit breaker before installing the fixture, in order to prevent possible shock.


## **GENERAL**

All electrical connections must be in accordance with local and National Electrical Code (N.E.C.) standards. If you are unfamiliar with proper electrical wiring connections obtain the services of a qualified electrician.

Remove the fixture and the mounting package from the box and make sure that no parts are missing by referencing the illustrations on the installation instructions.

### ASSEMBLY AND INSTALLATION

- 1. Place the base (11) on the floor.
- 2. Thread lower pole (10) into base (11) and turn clockwise to tighten securely.
- 3. Thread middle pole (9) into lower pole (10) and turn clockwise to tighten securely.
- 4. Thread upper fixture (8) into middle pole (9) and turn clockwise to tighten securely.
- 5. Squeeze legs of harp (4) together and insert the two ends between the prongs of the harp holder (6).
- 6. Place shade (3) and rubber washer (2) over harp (4) and secure with finial (1).
- 7. Install a 100 watt maximum medium base 3-way bulb (not included) into socket.



#### INSTALLATION IS NOW COMPLETED