

1500 Cherokee Parkway, Suite 100, Acworth, GA 30102

P: 866-845-5451 • F: 866-816-6165

E: service@acclaim-lighting.com • www.acclaim-lighting.com

# Item No . TF5685-07/TF5685-26 INSTALLATION INSTRUCTIONS

Please read carefully and save these instructions, as you may need them at a later date.

### **CAUTION**

WARNING: Risk of Fire. Consult a qualified electrician to ensure correct branch circuit conductor. Min 90°C supply conductors.

Turn off the main power at the circuit breaker before installing the fixture, in order to prevent possible shock.


### **GENERAL**

All electrical connections must be in accordance with local and National Electrical Code (N.E.C.) standards. If you are unfamiliar with proper electrical wiring connections obtain the services of a qualified electrician.

Remove the fixture and the mounting package from the box and make sure that no parts are missing by referencing the illustrations on the installation instructions.

## ASSEMBLY AND INSTALLATION

- 1. Thread three upper poles (9) into lamp body (8) and turn clockwise to tighten securely.
- 2. Thread three lower poles (10) into upper poles (9) and turn clockwise to tighten securely.
- 3. Place the fixture body in an upright position on the floor.
- 4. Squeeze legs of harp (4) together and insert the two ends between the prongs of the harp holder (7).
- 5. Place shade (3) and rubber washer (2) over harp (4) and secure with finial (1).
- 6. Install a 150 watt maximum medium base 3-way bulb (not included) into socket.



#### **INSTALLATION IS NOW COMPLETED**