

SAFETY INFORMATION

Please read and understand this entire manual before attempting to assemble, install or operate the product.


WARNING

- RISK OF ELECTRIC SHOCK - Before beginning installation, turn off electricity at the circuit breaker box or the main fuse box.
- RISK OF FIRE - Use bulbs specified by the markings and/or labels on the fixture.

CAUTION

- For your safety, read instructions completely before beginning installation.
- If in doubt about electrical installation, consult a licensed electrician.
- Turn off electricity to fixture before replacing the bulb(s).

TOOLS REQUIRED




CARE AND MAINTENANCE


- Wipe clean using soft, dry cloth or static duster. Always avoid using harsh chemicals and abrasives to clean fixture as they may damage the finish.

If you need further assistance call Quoizel Customer Care at 1-800-645-3184(9:00am - 5:00pm EST), or visit us on-line at www.quoizel.com

PACKAGE CONTENTS



MOUNTING HARDWARE



INSTALLATION

1 Unfold Arms

2 Install Fixture Body and Support Arms Assembly

3 Install Rod With Loop

4 Install Crossbar Assembly

Outlet Box

Canopy Lock Ring

5 Install Fixture Chain

OPTIONAL: Adjust Chain as desired, using pliers and soft cloth (neither included).

* Ceiling Canopy shape is varies depends on item purchased.

Ceiling Canopy

Canopy Lock Ring

Suggested chain length for Ceiling height:
 9 feet ceiling: use 4 link of chain and 2 quick links
 10 feet ceiling: use 14 links of chain and 2 quick links
 11 feet ceiling: use 24 links of chain and 2 quick links.

6 Pull Supply Wires

Pull the supply wires with ground wire through the chain alternate links.

7 Wiring

White wire from supply Ribbed side of wire from fixture identified with the label "N"

Black (or red) wire from supply Smooth side of wire from fixture identified with the label "L"

Ground wire from supply Green ground wire

Ground wire from fixture identified with the label "G"

8 Install Ceiling Canopy

* Ceiling Canopy shape is varies depends on item purchased.

9 Install Glass Shade and Bulbs

Install six correct bulbs referring to fixture markings and/or labels for maximum wattage.

Recommended Bulb Type (not included):

<p>BULB BASE TYPE Candelabra (E12)</p>	<p>BULB SHAPE TYPE B</p>
--------------------------------------------	------------------------------

Your installation is now complete! Restore electricity and save this sheet for future reference.