

ASSEMBLY INSTRUCTIONS

ITEM NO : BO-342-AB/BS/RU/DB

1. CAREFULLY UNPACK AND LAY OUT THE PARTS AS SHOWN IN ILLUSTRATION.


2. SCREW THE TUBE (B), COLUMN (C) AND SOCKET PART (D) INTO THE BASE (A) IN TURN.

3. INSERT THE HARP (F) INTO THE SADDLE OF THE SOCKET PART (D).

4. PUT THE SHADE (NOT INCLUDED) ONTO THE HARP (F) AND SCREW THE FINIAL (E) TIGHTLY.

5. INSERT THE POLARIZED PLUG INTO OUTLET, TURN ON THE SWITCH.

6. USE 3 WAY 150W (MAXIMUM) TYPE A BULB (BULB NOT INCLUDED). INSTALL BULB INTO THE SOCKET AND ENJOY YOUR LAMP.



IMPORTANT SAFETY INSTRUCTIONS :

THIS PORTABLE LAMP HAS A POLARIZED PLUG (ONE BLADE IS WIDER THAN THE OTHER) AS A FEATURE TO REDUCE THE RISK OF ELECTRIC SHOCK. THIS PLUG WILL FIT IN A POLARIZED OUTLET ONLY ONE WAY. IF IT DOES NOT FIT FULLY IN THE OUTLET, REVERSE THE PLUG. IF IT STILL DOES NOT FIT, CONTACT A QUALIFIED ELECTRICIAN. NEVER USE WITH AN EXTENSION CORD UNLESS THE PLUG CAN BE FULLY INSERTED. DO NOT ALTER THE PLUG.

SAVE THESE INSTRUCTIONS FOR FUTURE REFERENCE