

INSTALLATION INSTRUCTIONS

Item#6255-076 6258-076 6259-076 (New. 07/18/2022)

READ AND SAVE THESE INSTRUCTIONS

WARNING! SHUT POWER OFF AT FUSE OR CIRCUIT BREAKER.
AVERTISSEMENT! COUPER LE COURANT AU NIVEAU DES FUSIBLES OU DU DISJONCTEUR.

ASSEMBLING THE FIXTURE (Fig. 1)

1. Shut off the power at the fuse box or circuit breaker. If necessary, remove old fixture, including mounting hardware.
2. Carefully remove fixture from carton and check that all parts are included as shown in the illustration.
3. Adjust arms (H) to proper position. Refer to illustration (A).
4. Thread all thread (D) into bottom of fixture body (C). Place cover (E) over all thread (D) and screw finial (F) into all thread (D) until secure.
5. Carefully feed fixture wires through rod (B) and screw rod (B) to all thread on top of fixture body (C).

MOUNTING THE FIXTURE (Fig. 2)

6. Thread all thread into ceiling loop until snug.
7. Thread the other end of all thread into crossbar. Note: The length of all thread into crossbar may be adjusted if necessary.
8. Secure all thread to crossbar with hex nut.
9. Take crossbar assembly and mount it to outlet box using the mounting screws (Size: #8-32N*L1"). The side of crossbar marked "GND" must face out.
10. Open quick link and connect to fixture loop, then close quick link.
11. By measuring, determine the correct number of links needed for desired hanging height. Using chain pliers, disconnect and discard excess chain.
12. Carefully lace fixture wires through chain.
13. Slip lock collar and canopy over chain and allow them to rest on fixture body (C).
14. Open quick link and attach it to ceiling loop, then close quick link.
15. Carefully feed fixture wires through ceiling loop and all thread and pull until tight.

CONNECTING THE WIRES (Fig. 3)

16. Connect the electrical wires as shown in Fig. 3 making sure that all wire connectors are secured. If your outlet box has a ground wire (green or bare copper), connect the fixture's ground wire to it. Otherwise, connect the fixture's ground wire directly to the crossbar using the green screw provided.
17. Tuck wire connections neatly into outlet box. Raise canopy to ceiling and secure with lock collar.


FINISHING THE INSTALLATION (Fig.1)

18. Install candelabra base bulbs up to 60 watts each or CFL or LED equivalent (not included) in accordance with the fixture specification—**DO NOT EXCEED THE MAXIMUM WATTAGE RATING! (NE PAS DEPASSER LA PUISSANCE NOMINALE MAXIMALE!)**.

Your installation is now complete. Return power to the outlet box and test the fixture.

Note: Illustration (Fig. 1) on this manual is for installation purposes only. It may or may not be identical to the fixture purchased.

Fig. 1



Set# A-010

-Crossbar


-Ground screw

-Mounting Screw *2

Candle Cover 1# CCV20105P-076 (6255-076)


Candle Cover 2# CCV20136P-076 (6258-076 6259-076)

Fig. 2



Chain # HCH2072-076

Fig. 3



Notice: It is important to use proper chain pliers (not included) To OPEN and CLOSE the chain included with this fixture. Do not open them with other tools that may twist or stress the chain links. It is important to use proper chain pliers like the ones shown in the diagram.

