
## **ASSEMBLY INSTRUCTIONS**



# Basden 30" Adjustable Buffet Lamp

Item # CHA8081

#### **NOTICE:**

This light fixture should be installed in accordance with all applicable, local installation codes, and by a person familiar with the construction and operation of it, as well as the hazards involved. Inspect item and contents carefully. If any damage or defect is found, do not install. Retain all packaging material until installation is complete and approved.

### **TOOLS REQUIRED (NOT INCLUDED):**

#### Scissors

- 1. Carefully remove all parts from the box. Place on a clean, soft surface.
- 2. Install light bulb into the socket.
- Remove shade (A) from packaging and clip onto light bulb.
  NOTE: If shade has additional packaging, carefully cut off from interior of shade to avoid damages.
- To adjust fixture height loosen adjustment knob (C), then push up or down on fixture rod (B) and adjust to desired position.
   NOTE: Help feed electrical cord in or out of lamp for smoother adjustment.
- 5. Remove protective cover (F) from the plug.
- 6. Plug into electrical outlet and test fixture.

**Care Instructions:** Clean only with a soft dry cloth or feather duster. Do not use abrasive or chemical agents.





