
ASSEMBLY AND INSTALLATION INSTRUCTIONS

H0123 / H0124

WARNING: TO AVOID RISK OF ELECTRICAL SHOCK, BE SURE TO SHUT OFF POWER WHILE INSTALLING OR SERVICING THIS FIXTURE.

NOTES: 1. Before installing, consult local electrical codes for wiring and grounding requirements. 2. READ AND SAVE THESE INSTRUCTIONS.




- 5. Thread the fixture wire through the hex nut, threaded pipe and mounting strap. Install the hex nut onto one end of the threaded pipe leaving about 3/8" (10mm) thread exposed. Install same end of threaded pipe by screwing into coupling kit, secure threaded pipe by tightening hex nut.
- 6. Attach the threaded pipe to the mounting strap, then secure it with a washer and hex nut.
- 7. Attach the mounting strap to outlet box by using two mounting screws.
- 8. Pull out the source wires from the outlet box. Make wire connections using wire nuts as follows:
 - ---Connect the smooth-coated wire (marked) from the fixture to the hot wire (usually black insulation) from the power source.
 - ---Connect the ribbed-coated wire (unmarked) from the fixture to the neutral wire (usually white insulation) from the power source.
 - ---Attach the fixture grounding wire (usually bare wire) to the mounting strap with the green grounding screw. Then connect it to the house grounding wire with a wire nut. If your outlet box does not have a house grounding wire, then wrap the fixture grounding wire around the green grounding screw.


Carefully put the wires back into the outlet box.


- 9. Attach the canopy to the mounting strap: insert the coupling kit through hole, then secure by tightening collar.
- 10. Place the glass shades onto the glass brackets, then secure them by tightening the spacers and socket rings.
- 11. Install bulbs (not included). See relamping label at socket area or packaging for maximum allowed wattage.
- 12. Angled mounting recommended for a vaulted or angled ceiling. (See Fig. 1)

Turn on the power at the main fuse or circuit breaker box.



The following parts are available for re-order if damaged or missing.





A: 26"

B: 28-1/4~82-1/4"



Page 2