
Assembly Instructions: 3218-S/L & 3219-S/L (Dixon)

IMPORTANT:

- ALL INSTALLATION WORK SHOULD BE DONE BY ACCREDITED PROFESSIONAL.
- SHUT OFF POWER SUPPLY AT FUSE OR CIRCUIT BREAKER!
- USE ONLY THE SPECIFIED BULBS. DO NOT EXCEED THE MAXIMUM WATTAGE!

For Customer Service, please contact the place of purchase.



How to Identify the Fixture's Wires <u>Hot</u> Neutral Ground Smooth Ribbed Bare Metal. Green, or Black White Green Inner Thread White Inner Black Inner Ground Thread Thread

PREPARING FOR INSTALLATION

Remove all of the contents from the carton. See the important notes above. Shut off the power at the circuit breaker and completely remove the old fixture from the ceiling, including the old mounting strap.

- 1. Take the mounting strap assembly from the parts bag. Mounting strap (B) should have mounting screws (D) attached. You may need to tighten hex nuts (C) that hold the screws in place.
- 2. Use mounting screws (A) and a screw driver to attach mounting strap (A) to the junction box.

ASSEMBLING THE FIXTURE

3. Rods (K) are on the fixture's wires. By measuring, determine the correct number of rods needed for proper hanging height. There are three optional 12 inch rods and one 6 inch rod (J) included.

To lengthen the fixture, add additional rods. If additional rods are needed, contact the place of purchase to order.

To shorten the fixture, add at least 8 to 10 inches of wire to the desired length and trim the wires. Slide any excess rods off the fixture's wires to discard.

- 4. Pull the wires taut through the rods before threading the rods together. Thread bottom rod (J) onto post (M) at the center of the fixture's body.
- 5. Twist the top rod (J or K) into the threads of swivel post (I) of canopy (F). Lock the rod(s) into the canopy by twisting thumb screw (G). Pull the fixture's wires through the top of canopy (F) to connect with the house wires.

CONNECTING THE WIRES

6. Have an assistant support the weight of the fixture while completing the wiring. Cut away excess wire. Thread the fixture's wires through canopy loop (H) and nipple (F). Attach the fixture's wires to the power supply wires from the junction box. Connect black to black (or smooth); white to white (or ribbed); ground to ground (green or copper). Twist the ends of the wire pairs together, and then twist on a wire connector. Make sure all twists are in the same direction. If there is no ground wire (green or copper) coming from the junction box, locate ground screw (E) on mounting strap (A) and wrap the fixture's ground wire around the green ground screw (E). Use a screwdriver to secure ground screw (E) onto the mounting bracket. Tuck all wires neatly into the junction box.

FINISHING THE INSTALLATION

- 7. Raise canopy (F) to the ceiling. Position mounting screws (D) so that they protrude through the openings of canopy (F). Secure canopy (F) to mounting strap (B) with decorative nuts (H).
- 8. Install a light bulb (not provided) in accordance with the fixture's specifications. Do not exceed the maximum recommended wattage.
- 9. Loosen bolt (M) and raise lid (N) to the highest position. Tilt the lamp and rods slightly, and then pass the lamp through decorative cap (O) and into glass shade (P). Then, place decorative cap (O) and lid (N) on top of glass shade (P). Move the lamp and rods into a vertical position. Check that everything is level and secure the assembly by tightening bolt (M).

Your installation is complete. Turn on the power and test the fixture.

CLEANING TIPS

Treat the fixture gently! Regular cleaning will reduce the need for deep cleaning. For regular cleaning, turn off the light and wipe down the fixture with a clean lint-free cotton or microfiber cloth. Never spray cleaner directly onto the fixture.

