


BARUCH 1824 INSTALLATION INSTRUCTIONS



| ITEM | DESCRIPTION | PART NUMBER |
|------|------------------|-------------|
| 1 | MOUNTING PLATE | X |
| 2 | MOUNTING SCREW | X |
| 3 | GROUND SCREW | X |
| 4 | WIRE NUT | X |
| 5 | FIXTURE ASSEMBLY | X |
| 6 | M4 SET SCREW | X |
| 7 | RING | X |
| 8 | BULB | X |
| 9 | SHADE | X |

MARNING/CAUTION

- DISCONNECT POWER BEFORE RE-LAMPING OR WIRING THE FIXTURE. READ ALL INSTRUCTIONS
 COMPLETELY BEFORE STARTING INSTALLATION.
- TO AVOID THE RISK OF FIRE OR SHOCK, FIXTURE MUST BE INSTALLED IN COMPLIANCE WITH ALL
 APPLICABLE NATIONAL AND LOCAL ELECTRICAL/BUILDING CODES. THE INSTALLATION AND
 MAINTENANCE OF THIS UNIT SHOULD BE COMPLETED BY A LICENSED ELECTRICIAN OR CERTIFIED
 FACTORY TRAINED TECHNICIAN.
- CALIFORNIA PROP 65: THIS LIGHTING FIXTURE CONTAINS CHEMICALS KNOWN TO THE STATE OF CALIFORNIA TO CAUSE CANCER, BIRTH DEFECTS, AND/OR OTHER REPRODUCTIVE HARM. WASH HANDS AFTER LISE
- REMOVE THE FIXTURE, PARTS AND PARTS BAG(S) FROM THE CARTON, BEFORE DISCARDING THE CARTON, DOUBLE CHECK TO MAKE CERTAIN THAT ALL PARTS ARE FOUND. INSPECT THE FIXTURE PRIOR TO INSTALLATION FOR ANY DAMAGE TO THE FIXTURE.
 - DIMMING: THE FIXTURE CAN BE CONTROLLED BY A WALL DIMMING DEVICE. ONLY USE TRIAC/ELECTRONIC DIMMER. MAKE SURE THE CARTON IS MARKED FOR USE WITH LED COMPACT FLUORESCENT-INCANDESCENT LIGHT SOURCE ONLY. THESE CAN BE PROVIDED BY YOUR LOCAL ELECTRICAL DISTRIBUTOR, HOME CENTER, OR HARDWARE STORE.
 - PLEASE CLEAN WITH A SOFT, DRY CLOTH ONLY! DO NOT USE CLEANSERS.

FIXTURE INSTALLATION

- Attach the MOUNTING PLATE (1) unto the junction box using the MOUNTING SCREWS (2). This fixture is
 designed to be mounted on standard "GEM" wall box. The "GEM" wall box must be securely mounted to the
 structure of the building.
- Attach the Ground wire (Green) to the ground inside the outlet box (Generally green or bar copper wire) or the GROUND SCREW (3) on the MOUNTING PLATE (1). NEVER CONNECT GROUND WIRE TO "HOT" WIRE! FAILURE TO FOLLOW THIS COULD RESULT IN SERIOUS INJURY OR DEATH!
- Connect the white fixture lead to the neutral (Generally white) wire in the outlet box. Fasten the wires together
 with an approved fastener (WIRE NUT) (4). Starting 1" below the fastener, tightly wrap the connection with
 electrical tape so that the connections seals the end of the fastener. MAKE SURE THERE ARE NO EXPOSED
 WIRE OF STRANDS THAT COULD CAUSE A DANGEROUS SHORT CIRCUIT!
- Connect the black fixture leads to the hot (Generally black) wire in the junction box. Fasten the joined wires same as previous step. NEVER REVERSE HOT AND NEUTRAL WIRES. FAILURE TO FOLLOW THIS COULD RESULT IN SERIOUS INJURY OR DEATH!
- 5. Attach the FIXTURE ASSEMBLY (5) to the MOUNTING PLATE (1) and secure with the SET SCREWS (6)
- 6. Screw the BULB (8) up into the SOCKET of the fixture. THIS FIXTURE IS RATED FOR 7 WATT LED TYPE T10 LAMP. DO NOT EXCEED THE RECOMMENDED WATTAGE!
- 7. Attached the SHADE(9) to the FIXTURE ASSEMBLY then secure it with the RING(7) .
- 8. Restore power to the outlet at the breaker or fuse box.