

Assembly Instruction Sheet #IS-9610P4 For Style 9610P4

Total Runtime: Estimated 15 minutes, Philips screwdriver, pliers, wire cutters, wire strippers, electrical tape, safety glasses.

Light Source: (1) E26 BULB 60W MAX (Not Included)



Estimated Assembly Time: 15-30 minutes

Preparation: Identify and inspect all parts before beginning installation. Check packages content list and diagrams below to be sure all parts are present. If any parts are missing or damaged, do not attempt to assemble, install, or operate the fixture. Contact customer service for replacement parts.

⚠ Warnings and Cautions


Turn off electricity at circuit breaker or main fuse box before installation. Consult a licensed electrician if in doubt. These instructions are provided for your safety. It is very important you read them completely before installing the fixture. We strongly recommend that a licensed, professional electrician perform the installation. Disconnect fixture from power source before replacing bulbs. Make sure bulbs are given sufficient time to cool before removal.

Package Contents




Hardware Contents

PART	DESCRIPTION	QUANTITY
BB	Wire nut	2pcs
CC	Outlet Box Screw	2pcs




STEP 3 - Wire Connections


A. Use standard wire connectors to make all wire connections. Twist connection until wires are tightly joined together. Wrap each connection with approved electrical tape and carefully stuff all the connected wires into the Outlet box.



STEP 4 - Install Ceiling Canopy to Ceiling



STEP 5 - Loosen the screw .



STEP 6 - Install Bulb.

