

INSTALLATION INSTRUCTION

WS-W230301 / WS-W230302



CAUTION: To prevent electrical shock, ensure electricity has been turned off at the circuit breaker before beginning.

- Read all instructions before installing.
- Fixture is intended for installation by a licensed electrician in accordance with the National Electrical Code (NEC) and local regulations.
- When handling the fixture, do not apply pressure to the LEDs.
- Retain installation instructions for future maintenance reference.

WARNING: All parts must be used as indicated in these instructions. This product is designed for use only with the supplied parts and/or accessories designated for use by WAC Lighting. Substitution of parts or accessories not designated for use with this product by WAC Lighting could result in personal injury or property damage, and will void the warranty. Contact an authorized dealer or the manufacturer if any parts are damaged or missing.

MAINTENANCE NOTE: Coastal conditions may cause mineral and residue build-up on the fixture. We recommend that customers in coastal areas clean all external surfaces of the fixture once every two weeks with a wet cloth.


MISE EN GARDE: Pour éviter tout choc électrique, assurez-vous que le disjoncteur soit mis hors tension avant de commencer.

- Lisez toutes les instructions avant l'installation.
- Le système doit être installé par un électricien licencié conformément au code national de l'électricité (NEC), et également aux règlements locaux.
- Lors de la manipulation du luminaire, n'appuyez pas sur les LED. Tenez-le uniquement par la base.


ATTENTION: Toutes les pièces doivent être utilisées comme indiqué dans ces instructions. Ce produit est conçu pour être utilisé seulement avec les pièces et/ou accessoires fournis pour être utilisés avec les produits WAC Lighting. Remplacer des pièces ou accessoires non conçus pour ce produit WAC Lighting pourrait causer des dommages corporels ou matériels et pourrait également causer l'annulation de la garantie. Veuillez contacter un revendeur autorisé ou le fabricant si des pièces manquent ou sont endommagées.

NOTE D'ENTRETIEN: Les conditions côtières peut causer une accumulation de minéraux et de résidu sur le luminaire. Nous recommandons aux clients qui résident dans les zones côtières de nettoyer toutes les surfaces externes du luminaire une fois toutes les deux semaines avec un chiffon humide.

PRODUCT PICTURE



WS-W230301



WS-W230302

HARDWARE



Wire Connector
Qty: 3pcs + 1Extra



Mounting Screw
Qty: 1Extra



Rubber Gasket
Qty: 1Extra

wacighting.com
Phone (800) 526.2588
Fax (800) 526.2585

Headquarters/Eastern Distribution Center
44 Harbor Park Drive
Port Washington, NY 11050

South East Distribution Center
1600 Distribution Ct
Lithia Springs, GA 30122

Central Manufacturing Facility
1700 South J Elmer Freeway
Suite 100
Cedar Hill, TX 75104


Western Distribution Center
1750 Archibald Avenue
Ontario, CA 91761

INSTALLATION INSTRUCTION


WS-W230301 / WS-W230302



Fig.1



Backplate



PREPARATION

1. Shut off the power at the circuit breaker and remove existing fixture, including the crossbar.
2. Carefully unpack your new fixture and lay out all the parts on a clear area. Be careful not to lose any small parts necessary for installation.

MOUNTING THE BACKPLATE (Fig. 1)

3. Remove the mounting screw (B) and the rubber gasket (C) to separate the fixture from the backplate(set aside).
4. Secure the backplate to the junction box using the original junction box screws.

Note: (i) It is recommended to use only original junction box screws or replacements provided by junction box manufacturer;
 (ii) The side of the back plate marked "GND" must face out, towards the installer.

INSTALL THE FIXTURE (Fig. 2)

5. Twist off the lamp body from the canopy.
6. Wrap locking nut with thread seal tape to act as a sealant.
7. Rotate the lamp body into the canopy.
8. Tighten locking nut to secure fixture position.

CONNECTING THE WIRES (Fig. 3)

9. Connect the fixture's wires to junction box wires using wire connectors (A) as shown in Fig. 3, make sure that all wire connectors are secured. If your outlet box has a green or bare copper ground wire, connect the fixture's ground wire to it. After all wires are connected, tuck them carefully inside the junction box.

COMPLETING THE INSTALLATION (Fig. 1)

10. Secure the fixture to the backplate using the mounting screw (B) and the rubber gasket (C), previously removed.
11. To prevent moisture from entering the outlet box and causing a short, use clear caulking (i.e. indoor/outdoor silicone sealant) to outline the outside of fixture canopy where it meets the wall. Leave a space at the bottom to allow moisture to escape (Fig.4).

ADJUSTING THE LUMINAIRE (Fig. 5)

Vertical Adjustment: Loosen locking screw, rotate fixture to desired angle ($\pm 90^\circ$), and tighten locking screw.

Rotation Adjustment: Loosen locking nut, rotate fixture to desired angle (360°), and tighten locking nut.

Fig.4 Sealing




Fig.5 Rotation Adjustment




Fig.2





Fig.3



wacighting.com
 Phone (800) 526.2588
 Fax (800) 526.2585

Headquarters/Eastern Distribution Center
 44 Harbor Park Drive
 Port Washington, NY 11050

South East Distribution Center
 1600 Distribution Ct
 Lithia Springs, GA 30122

Central Manufacturing Facility
 1700 South J Elmer Freeway
 Suite 100
 Cedar Hill, TX 75104

Western Distribution Center
 1750 Archibald Avenue
 Ontario, CA 91761