CAUTION: TO PREVENT ELECTRICAL SHOCK, ENSURE ELECTRICITY HAS BEEN TURNED OFF AT THE CIRCUIT BREAKER **BEFORE BEGINNING.**

- Read all instructions before installing.
- System is intended for installation by a licensed electrician in accordance with the National Electrical Code (NEC) and local regulations.
- When handling the fixture, do not apply pressure to the LEDs. Hold the fixture by the base only.
- Retain installation instructions for future maintenance reference.
- VENTRIX fixtures and channels feature separate data and power conductor systems. During installation and use, do not short the data or power conductors together by any means or damage may occur.

WARNING: All parts must be used as indicated in these instructions. This product is designed for use only with the supplied parts and/or accessories designated for use by WAC Lighting. Substitution of parts or accessories not designated for use with this product by WAC Lighting could result in personal injury or property damage, and will void the warranty. Contact an authorized dealer or the manufacturer if any parts are damaged or missing.

MISE EN GARDE: POUR ÉVITER TOUT CHOC ÉLECTRIQUE, ASSUREZ-VOUS QUE LE DISJONCTEUR SOIT MIS HORS TENSION AVANT DE COMMENCER.

- Lisez toutes les instructions avant l'installation.
- Le système doit être installé par un électricien licensié conformément au code national de l'électricité (NEC), et également aux règlements locaux.
- Lors de la manipulation du luminaire, n'appuyez pas sur les LED. Tenez-le uniquement par la base.

ATTENTION: Toutes les pièces doivent être utilisées comme indiqué dans ces instructions. Ce produit est conçu pour être utilisé seulement avec les pièces et/ou accessoires fournis pour être utilisés avec les produits WAC Lighting. Remplacer des pièces ou accessoires non conçus pour ce produit WAC Lighting pourrait causer des dommages corporels ou matériels et pourrait également causer l'annulation de la garantie. Veuillez contacter un revendeur autorisé ou le fabricant si des pièces manquent ou sont endommagées.

OVERALL FIXTURE DIMENSIONS


FIXTURE OVERVIEW


LED LUMINAIRE

S2SD

Dimming:

VENTRIX Stealth Downlights are intended for use on WAC Lighting's VENTRIX Channel systems.





SPECIFICATIONS			
Input:	48VDC		
Installation:	VENTRIX System		

Refer to CPU Specifications.

Via VENTRIX Connected Power Unit.

VENTRIX SYSTEM

48VDC VENTRIX System

Phone (800) 526.2588		Headquarters, East Manuf
		44 Harbor Park Drive
Fax	(800) 526.2585	Port Washington, NY 11050

facturing Facility 0

South East Manufacturing Facility 1600 Distribution Ct Lithia Springs, GA 30122

Central Manufacturing Facility 1700 South J Elmer Freeway, Ste 100 Cedar Hill, TX 75104

West Manufacturing Facility 1750 S Archibald Ave Ontario, CA 91761

INSTALLATION INSTRUCTIONS **VENTRIX - Stealth Downlights** S2SD

VENTRIX


PREPARATION:

- Shut off the power at the circuit breaker and ensure adequate room to install the new fixture on the VENTRIX Channel system. 1.
- Carefully unpack your new fixture and lay out all the parts on a clear area. Be careful not to lose any parts necessary for installation. 2.

FIXTURE INSTALLATION TO VENTRIX SYSTEM:

The fixture features a VENTRIX adapter for power and mechanical connection to the installed VENTRIX channel system.

- This fixture may be installed into horizontally or vertically mounted VENTRIX channel systems. (See FIG. 1). 1.
- Fixtures are polarity agnostic, and may be installed in VENTRIX channel in either orientation. (See FIG. 2). 2.
- Insert the fixture into the channel slot. Ensure the fixture is parallel to the channel during installation. Push the fixture into the channel until 3. you hear a click and fixture is fully secured. NOTE: Fixture adapters also feature magnets to aid in fixture locating. (See FIG. 3 & 4). CAUTION: Prior to installation in channel, clear any debris from channel bus bar and fixture, particularly on magnetic surfaces. Any conductive elements have potential to cause electrical shorting resulting in damage.
- Review connection, be the fixture body's set sure the locking tabs AND ball bearings are secured in channel prior to finishing installation. 4.



waclighting.com Phone (800) 526.2588 (800) 526.2585 Fax

Headquarters, East Manufacturing Facility 44 Harbor Park Drive Port Washington, NY 11050

South East Manufacturing Facility 1600 Distribution Ct Lithia Springs, GA 30122

Central Manufacturing Facility 1700 South J Elmer Freeway, Ste 100 Cedar Hill, TX 75104


West Manufacturing Facility 1750 S Archibald Ave Ontario, CA 91761

RELOCATING THE FIXTURE IN CHANNEL:

While installed to the VENTRIX system, the fixture may be relocated.

- 1. By hand, relocate the fixture within a channel by pushing the adapter in the desired direction. (See FIG. 5).
- 2. Fixtures cannot be relocated between channels. It must be removed, repositioned, and then installed from one channel to another. (See **FIG. 6**).


NOTE: Ensure fixture element remains secure in channel during and after adjustments.



REMOVING THE FIXTURE FROM THE CHANNEL:

locking tabs.

- 1. By hand, engage and press the push button on the adapter, while holding the other end of the fixture. With push button pressed, pull the fixture away from the channel, until it is clear of the channel (See **FIG. 7**).
- NOTE: Ensure the adapter is parallel to the channel during removal. Removing the fixture at an angle may result in damage. (See FIG. 8).
 To enable fixture removal from channel, maintain free channel space of 1.5" on each side of adapter to enable access to releasing




waclighting.com West Manufacturing Facility Headquarters, East Manufacturing Facility South East Manufacturing Facility **Central Manufacturing Facility** Phone (800) 526.2588 1750 S Archibald Ave 44 Harbor Park Drive 1600 Distribution Ct 1700 South J Elmer Freeway, Ste 100 (800) 526.2585 Fax Port Washington, NY 11050 Lithia Springs, GA 30122 Cedar Hill, TX 75104 Ontario, CA 91761

REPLACING THE TRIM AND TIR LENS :

The Stealth Downlight trims may be replaced in field to change the decorative appearance of the fixture. Its TIR lens may be replaced to change its optical performance.

- 1. Power off the fixture and allow it to cool down.
- 2. Using a fingernail or small prying tool, separate the trim with TIR lens from the fixture housing.
- 3. By hand, separate the trim and TIR lens. Select the appropriate replacement components using model numbers. (See FIG. 9).
- 4. Reassemble the trim with TIR lens, and then install to the fixture housing.



waclighting.com Phone (800) 526.2588 Fax (800) 526.2585

Headquarters, East Manufacturing Facility 44 Harbor Park Drive Port Washington, NY 11050 South East Manufacturing Facility 1600 Distribution Ct Lithia Springs, GA 30122 **Central Manufacturing Facility** 1700 South J Elmer Freeway, Ste 100 Cedar Hill, TX 75104 West Manufacturing Facility 1750 S Archibald Ave Ontario, CA 91761