


# ASSEMBLY & INSTALLATION INSTRUCTIONS FOR POST LAMP



**Before starting the installation, disconnect the Power by Turning Off the Circuit Breaker. Turning the Power Off using the Light Switch is not sufficient to prevent electrical shock. All electrical connections and installation must be in accordance with local codes, ordinances and/or National Electric Code and Must Be Done by an Electrician Only.**

1. All three (3) Anchor Bolts must be assembled onto Mounting Bracket with 1 hex nut above and 1 hex nut below locking in Mounting Plate so that threaded portion protruding from Mounting Plate measures 1-1/2" (38mm) and cast into cement as shown on FIG.1. Anchor Bolts should extend 1-1/2" (38mm) out of the cement. After Post Base is placed on top of Cement Base, Anchor Bolts can not protrude more than 1/4" (6mm) from Post Base.

2. Connect Black wire to black supply box wire with an included UL Listed wire nut. Connect White wire to White Supply box Wire with an included UL Listed wire nut. Connect lantern copper ground wire to house ground wire with an electrical tape.

**NOTE:** Black supply box wire maybe red, round and smooth and/or have a copper conductor. White supply box wire maybe square and ridged and /or have a silver conductor.

3. Once the cement is fully dried, place the Post Base over the Anchor Bolts and pull Electrical Wire through hole. Secure Post Base to concrete with three (3) Cap Nuts threaded over Anchor Bolts as shown on FIG.2A.

4. Pull Wire through Middle Column. Place Middle Column over Post Base aligning three (3) screw holes. Secure Middle column to Post Base by three(3) Machine screws supplied as shown on FIG.2B.

5. Pull Wire through Top Column, Thread Top Column into top of Middle Column and turn to tighten, as shown on FIG.2C.

6. Connect Black wires from lanterns to Supply Black wire with an included UL Listed wire nut. Connect White wires from lanterns to Supply White wire with an included UL Listed wire nut.

7. Thread lantern onto Top Column and turn to tighten, as shown on FIG.2D

**NOTE:** Make sure that Electrical Wiring Connections are made AFTER the lantern is treaded and secure.

8. Bulb Installation: Install 100 watt max., Type (A) Medium Base Bulbs(not included) in socket. As noted on relamping label located at socket area.