
## ASSEMBLY AND INSTALLATION INSTRUCTIONS

## P0095

WARNING: BE SURE TO SHUT OFF POWER AT THE MAIN FUSE OR CIRCUIT BREAKER BOX BEFORE INSTALLING OR SERVICING THIS FIXTURE.


NOTE: 1. Before installing, consult local electrical codes for wiring and grounding requirements. 2. READ AND SAVE THESE INSTRUCTIONS.




- 1. Thread two assembly screws to the mounting strap, and secure them with two lock nuts. Adjust the length of the assembly screws if necessary.
- 2. Attach the mounting strap to the outlet box by using two mounting screws.
- 3. Rod connections:
  - a. Thread the fixture wire from the fixture through the lower rod, and then secure the lower rod onto glass holder using the nipple.
  - b. Thread the fixture wire through the middle rod, and then secure the middle rod onto the lower rod using the nipple.
  - c. Thread the fixture wire through the upper rod, and then secure the upper rod onto the middle rod using the nipple.


The height can be adjustable to 9-3/4"  $\sim 54-3/4$ ", by using the rods.

- 4. Thread the fixture wire through the canopy kit, then secure the rod assembly to the set nipple of the canopy kit.
- 5. Pull out the outlet wires and the house grounding wire from the outlet box. Make wire connections using the wire nuts:
  - ---The black wire from fixture to the black wire from power source.
  - ---The white wire from fixture to the white wire from power source.



- ---Attach the fixture grounding wire to the mounting strap with the green grounding screw. Then connect it to the house grounding wire with the wire nut.
- Carefully put the wires back into the outlet box.
- 6. Attach the canopy to the mounting strap by inserting the assembly screws, and secure it with two ball nuts.
- 7. Attach the glass shade to the glass holder, then secure it with a spacer and socket ring.
- 8. Install a bulb (not included). See relamping label at socket area or packaging for maximum allowed wattage.
- 9. Turn on the power at the main fuse or circuit breaker box.
- 10. Angled mounting recommended for a vaulted or angled ceiling. (See Fig. 1)





A: 5"

B: 9-3/4" ~ 54-3/4"

