

ASSEMBLY INSTRUCTIONS

ITEM DESCRIPTION:

ITEM NO.: DFC11	NAME: CHAMBERS FLUSH MOUNT
MATERIAL TYPE: METAL+SILK	FINISH: ENGLISH BRONZE
SOCKET TYPE: E12	SOCKET QTY: 10
BULB WATTAGE: Type G 60W	
VOLTAGE: 100V-120V	ITEM NET WEIGHT: 10KG




FIG.1
(NOT INCLUDED)

PARTS INCLUDED:

Mounting Plate (A)	Qty:1PC	Anchor (Q)	Qty:1PC
Lamp Body (B)	Qty:1PC	Bracket(R)	Qty:1PC
Finial (C)	Qty:1PC	Coupling (Z)	Qty:1PC
Socket(H)	Qty:10PCS	Aircraft Wire(W)	Qty:1PC
Mounting Screw (J)	Qty:2PCS	Screw(S)	Qty:2PCS
Plastic Wire Connector (K)	Qty:3PCS	Strengthen Screw(T)	Qty: 1

HARDWARE INCLUDED:

Mounting Screws	2
Plastic Wire Connector	3
Green Ground Screw	1

TO INSTALL YOU WILL NEED:

- 2 people recommended
- Phillips Screwdriver

These instructions are provided for safety. It is very important that they are read carefully and completely before beginning installation of this chandelier.

We strongly suggest that all hard-wired fixtures must be installed by a professional electrician.



TO ASSEMBLE:

1. Shut off the main electrical supply from the main fuse box/ circuit breaker.
 2. Carefully unpack all fixture parts and hardware and lay them on a soft surface for assembly.
 3. Gently pull wiring down from ceiling junction box and allow to hang.
 4. Remove mounting plate(A) from the lamp body(B) by unscrewing turning the Finial (C) .
 5. Drill one hole on the ceiling and insert anchor(Q) into drilled hole. Then fix bracket(R) to the ceiling with strengthened screw (T) by screwing into anchor(Q). Remove the coupling(Z) from the aircraft wire(W) by loosening (2) screws(S). Pass the aircraft wire(R) through (2) holes on the bracket(R). Then pass the aircraft wire(W) through (2) holes on the coupling(Z) and fix with (2) screws(S) as FIG1 .or you can find more details on next page. Be sure to tighten two screws attached on the coupling(Z).
 6. Carefully inspect the flush mount's fixture wires.
Neutral fixture wire: White
Hot fixture wire: Black
Ground wire: Bare wire
 7. Wrap ground wire of lamp assembly and ground wire of junction box together and fasten together with a wire nut and wrap the connection with electrical tape.
 8. Attach the neutral fixture wire from the flush mount to the neutral junction box wire (usually white). Fasten each together with a wire nut and wrap the connection with electrical tape.
 9. Attach the hot fixture wire from the flush mount to the hot junction box wire (usually black). Fasten each together with a wire nut and wrap the connection with electrical tape. DO NOT REVERSE THE HOT AND NEUTRAL CONNECTIONS OR SAFETY WILL BE COMPROMISED.
 10. Gently tuck the wire connections(K) neatly into the ceiling junction box.
 11. Place the mounting plate(A) over the center of the ceiling junction box.
 12. Align holes in mounting plate(A) with holes in junction box and attach with two mounting bolts(J). Secure bolts with a Phillips head screwdriver.
 13. Attached lamp body(B) to the mounting plate(A) until it is flush with the ceiling. Secure by turning the Finial (C) .
 14. Insert 10 TYPE G 60W bulbs (OR /CFL 12W OR /LED 10W, not included) into the socket(H).
- DO NOT EXCEED THE SPECIFIED WATTAGE.
14. Restore power to the junction box and test fixture.

CARE INSTRUCTIONS:

Wipe with a soft, dry cloth. To protect finish, avoid the use of chemicals and household cleaners.

For customer service questions call 1-800-338-2150

ARTERIO RS

AIRCRAFT WIRE ASSEMBLY INSTRUCTIONS

1. Attach the AIRCRAFT WIRE(Q) to a solid structure in accordance to local building code.
2. Position the BRACKET(R) in desired location on ceiling and mark one spot with pencil to drill hole.
Drill 1 hole on the spot and insert ANCHOR(C) into drilled hole.
3. Fix BRACKET(R) with STRENGTHENED SCREW (E) by screwing into ANCHOR(C).
If attach to cement ceiling, use ANCHOR(C) first then screw STRENGTHENED SCREW (E) into the ANCHOR(C).
If attach to wood ceiling, thread STRENGTHENED SCREW (E) directly into ceiling.
4. Remove the COUPLING(S) from the AIRCRAFT WIRE(Q) by loosening the (2) SCREWS(P) before installation.
5. Pass the AIRCRAFT WIRE(Q) through the (2) holes on the BRACKET(R) as the drawing shows.
6. Then pass the AIRCRAFT WIRE(Q) through the (2) holes on the COUPLING(S) and fix with (2) SCREWS(P).
And then tighten (2) SCREWS(P). with a screwdriver.

