

## NOX-4 Series Onyx 4" LED Retrofit

INSTALLATION SHOULD BE CARRIED OUT BY YOUR LOCAL ELECTRICIAN.

**ALWAYS TURN OFF MAIN POWER BEFORE INSTALLATION**

### **WARNING: Fire/Electrical Hazard**

This equipment is intended to be installed only by qualified personnel. The installation must be made in accordance with the current edition to the National Electric Code and all applicable state and local building codes. The final installation must be approved by the appropriate qualified electrical/building inspector(s). Improper installation may result in a fire or electrical hazard. Be sure the electrical power to the circuit has been disconnected before installing this electrical system.

### **AVERTISSEMENT : Fire / Risque électrique**

Cet équipement est destiné à être installé uniquement par du personnel qualifié . L'installation doit être faite en conformité avec l'édition actuelle du Code national de l'électricité et toutes étatiques et locales codes du bâtiment applicables . L'installation finale doit être approuvée par l' inspecteur en électricité / bâtiment qualifié approprié ( s ) . Une mauvaise installation peut entraîner un incendie ou un risque électrique . Soyez sûr de la puissance électrique vers le circuit a été coupée avant l'installation de ce système électrique .

### A.PACKAGING CONTENTS

- a.SOCKET ADAPTER ASSEMBLY (Figure.1)
- b.RECESSED TRIM(Figure.1)




Figure.1

### B.HOUSING DIMENSIONS




Figure.2

MIN. LAMP COMPARTMENT DIMENSIONS 105(DIA) X 144 (H) mm

### C.PERFORMANCE SUMMARY

Input Voltage: 120Vac  
Light Output (Lumens): 650L  
Watts: 10.5W  
CCT: 3000K  
CRI: 90  
Lifetime: 36,000 hours

### D.INSTALLATION INSTRUCTIONS

Remove mounting BRACKET and plate from inside existing RECESSED HOUSING. (Figure2)  
Screw the SOCKET ADAPTER into existing SOCKET in housing. (Figure.3)




Figure.3

Plug the FEMALE CONNECTOR of the RECESSED TRIM into the MALE CONNECTOR of the SOCKET ADAPTER ASSEMBLY. (Figure.4)




Figure.4

Tuck all wires into the RECESSED HOUSING and carefully push the RECESSED TRIM into RECESSED HOUSING. (Figure.5)




Figure.5